


Installation Guide


Service kits



A	PN	DN	Δp (bar)							Code No.
			$0.05 \div 0.5$ $0.1 \div 0.5$	$0.2 \div 1.0$	$0.3 \div 2.0$	$0.8 \div 1.6$	0.2	0.3	0.5	
	16	15 ÷ 32	-	×		-	×	-	-	003H1330
			-	-		-	-	×	-	003H1326
			-	-		-	-	-	×	003H1331
			-	-		×	-	-	-	003H1332
	25	15 ÷ 50		-	-		×		-	88835920
		15 ÷ 25		-	-		-		×	88835930
		32 ÷ 50		-	-		-		×	88835940















B	PN	DN	Δp_s (bar)							Code No.
			$0.1 \div 0.5$	$0.2 \div 1.0$	$0.3 \div 2.0$	$0.8 \div 1.6$	0.2	0.3	0.5	
	16	15 ÷ 32					×			003H1330
	25	15 ÷ 25					×			88835920
		32 ÷ 50					-			-










































M1	CuSn5ZnPb (Rg5)
M2	EN-GJS-400-18-LT (GGG 40.3)

























2	PN 25	AVP, AVP-F, AVPB, AVPB-F, AVPBT-F, AVD, AVQ, AVQT, AVQM, AVQMT	M1
2	PN 25	AVP, AVP-F, AVPB, AVPB-F, AVPBT-F, AVD, AVQ, AVQT, AVQM, AVQMT	M2
3	PN 25	AVPQ, AVPQ-F	M1
3	PN 25	AVPQ, AVPQ-F	M2
4	PN 25	AVPQ 4, AVPQ 4-F	M1
4	PN 25	AVPQ 4, AVPQ 4-F	M2
5	PN 25	AVPA	M1
5	PN 25	AVPA	M2

Installation Guide Service kits

PN 25	AVP, AVP-F, AVPB, AVPB-F, AVPBT-F, AVD AVQ, AVQT, AVQM, AVQMT	A B	M1	PN 25	AVP, AVP-F, AVPB, AVPB-F, AVPBT-F, AVD AVQ, AVQT, AVQM, AVQMT	M2
<p>1</p> 	<p>2</p> 	<p>1</p> 	<p>2</p>  <p>3</p> 			
<p>3</p>  <p>AVD →</p>	<p>4</p> 	<p>4</p>  <p>88835920</p> <p>003H6758 AVQM DN 50 - flange 003H6782 AVQMT DN 50 - flange</p>	<p>5</p> 			
<p>5</p> 	<p>4</p> 	<p>7</p> 	<p>5</p>  <p>6</p> 			

PN 25 AVPQ, AVPQ-F	B M1	PN 25 AVPQ, AVPQ-F	M2
<p>1</p> 	<p>2</p> 	<p>1</p> 	<p>2</p>  <p>3</p> 
<p>3</p>  <p>1</p>  <p>2</p>  <p>1</p>  <p>2</p>  <p>1</p>  <p>2</p>  <p>1</p>  <p>2</p> 	<p>4</p>  <p>1</p>  <p>2</p>  <p>1</p>  <p>2</p> 	<p>7</p>  <p>1</p>  <p>2</p> 	<p>5</p>  <p>2</p>  <p>1</p>  <p>6</p>  <p>2</p> 
<p>5</p>  <p>1</p>  <p>2</p> 	<p>4</p>  <p>1</p>  <p>2</p> 	<p>7</p>  <p>1</p>  <p>2</p> 	<p>5</p>  <p>2</p>  <p>1</p>  <p>6</p>  <p>2</p> 

PN 25 AVPQ 4, AVPQ 4-F	B M1	PN 25 AVPQ 4, AVPQ 4-F	M2
<p>1</p> 	<p>2</p> 	<p>1</p> 	<p>2</p> 
<p>3</p> 	<p>4</p> 	<p>4</p> 	<p>3</p> 
<p>5</p> 	<p>4</p> 	<p>7</p> 	<p>5</p> 

PN 25	AVPA	M1	PN 25	AVPA	M2
<div>1</div> <div><p>PAM082.101</p></div>	<div>2</div> <div><p>PAM083.101</p></div>	<div>1</div> <div><p>PAM085.101</p></div>	<div>2</div> <div><p>PAM086.101</p></div>		
<div>3</div> <div><p>PAM084.101</p></div>		<div>3</div> <div><p>PAM087.101</p></div>			
<div>5</div> <div><p>PAM082.101</p></div>	<div>4</div> <div><p>PAM083.101</p></div>	<div>5</div> <div><p>PAM085.101</p></div>	<div>4</div> <div><p>PAM086.101</p></div>		

